

APARTMENT DOOR/INTERCOM INSTRUCTIONS

Each apartment is assigned a suite number starting from SUITE 1 to SUITE 8.

When a visitor arrives they can either press the number on the keypad associated with the apartment they need to call, or by pressing the scroll down/up button under the LCD display to display the apartment they want to call. Once the SUITE desired is selected either by touching the #1 button (SUITE1 will display on the LCD window) or scrolling until SUITE1 appears, then press the GREEN BELL BUTTON on the RT side under the LCD display to call the suite desired. The apartment tenant station will ring. To cancel the call at any time simply press the RED X button located under the LCD display.

The Tenant can answer the door simply by pressing the talk button. The light on the talk button will illuminate RED. A conversation can then begin with Tenant and visitor. To open the door once visitor confirmation is complete, simply PRESS and HOLD the KEY button. This will release the door lock mechanism and allow entry. Confirm with visitor that entry is complete.

Make sure door is completely closed. If not, door release will not function properly.